



Importing Design, As-BUILTs, and SUE from a File in RULIS

A RULIS Job Aid

Roles Impacted

Utility Consultant

Last Revised

January 3, 2024



Introduction

This job aid will review the different file types for importing vector files into your utility design.

Topics

- [Glossary](#)
- [Importing Geometries without Attributes](#)
- [Comma Separated Values \(.csv\)](#)
- [ESRI Shape File \(.zip\)](#)
- [KMZ File \(.kmz\)](#)
- [Importing Geometries with Attributes](#)
- [Comma Separated Values \(.csv\)](#)



Importing Vectors :

RULIS for Utility Permits provides features for importing vectors from external file sources.

The import functionality is divided into **two** major groups: importing utility vectors without attributes and importing utility vectors with attributes. Importing vectors without attributes will only import the geospatial coordinates of items on the map; attributes must be entered manually.

- **Vector** – A line or point on a map.
- **Attributes:** the alphanumeric data that describes the utility (e.g.. material, height, width, etc).

Importing Vectors without Attributes:

To import vectors without attributes, RULIS supports **three** major file formats:

- Comma separated values (.csv)
- Keyhole Markup Language Zipped (.kmz)
- ESRI Shape (.shp)




Comma Separated Values (.csv)

The **.csv** file must be arranged with the following header columns:

- Point ID
- Latitude
- Longitude
- Elevation

The “Point ID” column is used by the system to chain the points into a line. This means that if there are multiple points with the same Point ID the system will combine them into a line. On the other hand, records that have a unique Point ID will be uploaded to the system as a single point.

-  When uploading a **.csv** for design it is not required to have the Elevation column.

ESRI Shape File (.zip)

The file must be a **.zip** containing the files that make up the SHAPE file, the files within the **.zip** should be:

- filename.shp
- filename.dbf
- filename.shx
- the .prj and any other file that make up the SHAPE are optional.



KMZ File (.kmz)

The file must be a **.kmz** file format. KMZ is one of the formats that can be exported from google earth.



NOTE: KMZ is a format that contains a **.kml** (Keyhole Markup Language) within **.zip** (compression file type).

- KMZ files can have lines and points.
- The coordinates must be in EPSG:4326.


Uploading Files


To upload a project that contains both lines and points (e.g., electric cable and poles), users should create **two** files:

1. Upload the file for the electric line, set up the attributes, and save.
2. Upload the file for the pole points, set up the attributes, and save.

To upload a file

1. Go to the Detail View.
2. Right click the **Utility Design** or **Utility As-Built** node (depending on where you are in the workflow).
3. Select Layer upload.
4. The Upload file window appears.
5. Select your file.





- The file projection must be in **EPSG:4326**.
- RULIS Utility Permit accepts ESRI shape files with geometries that can handle the Z (elevation) attribute.



Importing Geometries with Attributes

For importing geometries with attributes RULIS for Utility Permits supports **two** major file formats:

- Comma Separated Values (.csv)
- ESRI Shape (.shp).

Comma Separated Values (.csv)

There are **three** options which may be used in this case: only points, only lines.

- The “POINT ID” column is used by the system to chain the points into a line.
- If the CSV file contains multiple points with same “POINT ID,” the system will concatenate them into a line.
- On the other hand, records that have a unique value for “Point ID” will be uploaded to the system as a single point.